

Aufbauanleitung "IsoFrame Wave" Prospekthalter

Mounting instruction

Brochure holder system

Uncut wires

IS-9310 Wire system with 4 meter (157.5") wires

Pre-cut wires

IS-9311 Wire system for Midi 2470 mm (97.2") panels

IS-9312 Wire system for Maxi 2270 mm (89.4") panels

IS-9318 Brochure holders A4 / US letter with 4 connectors

Please observe: This system can only be used with a straight Compact or Straight graphic wing module



Mounting instruction

- 1** Push in the small H-profile at the top of the beam and then mount the extra beam in top of that profile.
- 2** Mount this assembly at top of the posts.
- 3** Attach the graphic panel and adjust the base beam so that its bottom edge aligns exactly with the bottom edge of the graphic.
- 4** Hook the top connector of the wire assembly to the top beam.
- 5** Mount the first bottom connector.
- 6** Screw the bottom fitting of the wire assembly into the connector until the wire is tight. Repeat the process with the top fitting.
- 7** Attach the four identical grip connectors to the brochure holder, evenly spaced. Do not over-tighten.
- 8** Remove the side screws in the grip connectors, position the wire inside the groove, and re-install the side screws.
- 9** You can now attach more brochure pockets.