

Aufbauanleitung "IsoFrame Wave" Vitrinen-Modul

Mounting instructions

Showcase modules - Single height

Item no: Midi IS-9410-1
Maxi IS-9410-2

Complete with:

1 Wave base post, 763 mm	Midi IS-9410-1	Maxi IS-9410-2
1 Extension post, 750 mm	IS-W763-BPH	IS-W763-BPH
1 Top post, 755 mm	IS-0750-EP	IS-0750-EP
3 Extension post, 200 mm	IS-0755-EP	IS-0755-EP
1 Wave foot	IS-WFT-02	IS-WFT-02
2 Base post	IS-0750-BP	IS-0750-BP
2 Extension post, 750 mm	IS-0750-EP	IS-0750-EP
2 Top post, 755 mm	IS-0755-TP	IS-0755-TP
5 Straight beam, 800	IS-800-S	IS-800-S
4 Straight beam, 400	IS-400-S	IS-400-S
1 Slotwall panel, black, 800	IS-SW-02	IS-SW-02
2 Slotwall panel, black, 400	IS-SW-04	IS-SW-04
1 Base shelf, black	IS-SW-08	IS-SW-08
2 Shelf bracket	IS-SW-10	IS-SW-10
1 Top shelf, White	IS-SW-09	IS-SW-09
2 corner trims, 763 mm	IS-0763-CT	IS-0763-CT
1 Kicks & Hangers	IS-800-KHN	IS-800-KHN

Accessories

Shelf bracket
800mm / 31.5"
Item IS-SBQ-19

Shelf, grey
800mm / 31.5" x 22.5x13.8"
Item IS-SBQ-05

Shelf, grey
400mm / 15.7" x 22.5x13.8"
Item IS-SBQ-06

- 1 Build the bottom housing of the showcase by connecting two 800mm/31.5" and two 400mm/15.75" standard beams.
- 2 First determine the desired height for the bottom shelf. Adjust the 6 stop screws so that the top edge of the stop screw is 105mm/4.1 inches below desired shelf height.
- 3 Mount the extension posts and move up the side and back beams to the top of the stop screw.
- 4 Slide the rear panel in place, from the top, and attach the shelf brackets on the bottom slot in the slotwall.
- 5 Insert the bottom shelf. Attach a 600 mm beam until it touches the bottom shelf.
- 6 Slide in the two side panels from the top.
- 7 Attach the four top posts, one 800 mm beam across the back, and two 400 mm beams on the sides at the top of the panels.
- 8 Mount the final 800 mm beam across the front, with top of beam even with bottom edge of the center slot in the side beams.
- 9 Slide in the top shelf in the track of the back side 800 beam.
- 10 This completes the Showcase.